

This Page Is Inserted by IFW Operations  
and is not a part of the Official Record

## **BEST AVAILABLE IMAGES**

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

**IMAGES ARE BEST AVAILABLE COPY.**

**As rescanning documents *will not* correct images,  
please do not report the images to the  
Image Problem Mailbox.**



# EMISSION SPECTROSCOPY OF $\text{CCl}_4$ AND $\text{BCl}_3$ PLASMAS DURING ALUMINUM ETCHING

By John E. Spencer and Betty Y. Shu  
MOS Process Development Laboratory  
Texas Instruments Incorporated

P.O. Box 1443 M/S 631, Houston, Texas 77001

and

Texas Instruments Incorporated  
P.O. Box 225621 M/S 976, Dallas, Texas 75265

## ABSTRACT

Spectroscopy of  $\text{BCl}_3$  and  $\text{CCl}_4$  plasmas shows major differences that can be related to their etch characteristics.  $\text{BCl}_3$  alone etches  $\text{Al}_2\text{O}_3$  readily, but etches aluminum slowly. Adding  $\text{Cl}_2$  reduces its effectiveness at etching  $\text{Al}_2\text{O}_3$ , but allows a very rapid aluminum etch. The spectra of  $\text{CCl}_4$  plasmas do not reveal major differences in chemistry with the addition of  $\text{Cl}_2$ . From spectral evidence the main difference between the two gases is that  $\text{CCl}_4$  is a much better source of atomic chlorine than is  $\text{BCl}_3$ . Plasmas of  $\text{CCl}_4$  alone,  $\text{CCl}_4$  plus  $\text{Cl}_2$ , and  $\text{BCl}_3$  plus  $\text{Cl}_2$  show a strong band emission at 257 nm due to  $\text{Cl}_2$ . This band can obscure the 261 nm band of  $\text{AlCl}$  that is often used as an endpoint signal. The intensity of this band is very sensitive to the presence of aluminum in the plasma. The  $\text{Cl}_2$  signal is quenched after etch initiation, when  $\text{AlCl}$  emission is detected. As the slice clears and the  $\text{AlCl}$  emission disappears, the  $\text{Cl}_2$  signal returns. The Al atomic emission lines at 394 and 396 nm have no interference and are suggested as better lines for end point detection.

## Introduction

Plasma spectroscopy offers an excellent window into the mechanism of plasma etching. This is particularly true when the etch has a large chemical component. In that case the plasma will emit the characteristic spectral emissions of both reactant and product species. This is already widely used in endpoint detection in silicon (1) and aluminum etching (2). This paper will examine the plasma emission spectra toward elucidating etching mechanisms of various gases in aluminum processing.

Two commonly used gases in Al thin film etching are  $\text{CCl}_4$  and  $\text{BCl}_3$ , either alone or in combination with  $\text{Cl}_2$ . Ar or He is usually added as a diluent. These gases show great differences in their spectral characteristics, especially in the region between 250 and 400 nm. Emissions from reactant gas fragments as well as  $\text{Cl}_2$ , Al, and  $\text{AlCl}$  are

ircuit shrunked  
llest resist  
resist on

observed in this region (3). Atomic Cl can be detected at 726 nm. These spectra can be related to their etching properties. Furthermore, examination of traces of both AlCl and Al emission during etching shows significant differences that should be taken into account in selecting an end point signal.

#### Experimental

All data reported here were obtained with a load-locked parallel plate plasma reactor with an anodized aluminum interior. Spectra were recorded with a quarter meter monochromator with 2 nm resolution. All plasma conditions were at 1.0 torr with 13.56 MHz excitation.

#### Results and Discussion

The spectrum of 1% CCl<sub>4</sub> in Ar shows bands due to Cl<sub>2</sub> at 257, 308 nm and CCl at 272-279 nm. No Al or AlCl emission is observed when the plasma is sustained in an empty anodized aluminum etch chamber. The addition of a small amount of Cl<sub>2</sub> equal to the CCl<sub>4</sub> in the plasma causes the CCl emission to be greatly reduced while emissions from Cl<sub>2</sub> and Cl grow in intensity.

The spectrum of 2% BCl<sub>3</sub>/Ar in an empty anodized aluminum chamber shows several major differences over the CCl<sub>4</sub> plasma. No Cl<sub>2</sub> emission is seen, and atomic Cl emission is weaker than with CCl<sub>4</sub>. BCl emission between 266 and 285 nm is very strong. The band of AlCl at 261 nm is seen with strong intensity, as are strong aluminum lines at 394, 396 nm, and weak aluminum lines at 308, 309 nm. The addition of a small amount of Cl<sub>2</sub> to the plasma removes any emission due to Al species, reduces the BCl emission, and results in strong Cl<sub>2</sub> emission.

BCl<sub>3</sub> is regarded as an excellent etch initiator with a rapid etch rate of native aluminum oxide. The spectral data corroborate this, since the presence of Al and AlCl emission from an anodized aluminum chamber is direct evidence of etching of aluminum oxide. The absence of Al emission from the empty chamber when CCl<sub>4</sub> is used suggests that BCl<sub>3</sub> is a much better aluminum oxide etchant than is CCl<sub>4</sub>. This is in contrast to a published report that states that CCl<sub>4</sub> is a faster etchant for aluminum oxide than is BCl<sub>3</sub> (4). Moisture contamination could not have been the reason for this difference since the load locks on the reactor always provided very reproducible etch initiation with both BCl<sub>3</sub> and CCl<sub>4</sub>. The addition of Cl<sub>2</sub> to the BCl<sub>3</sub> plasma suppresses Al emission, indicating that oxide etching becomes inefficient in the presence of added Cl<sub>2</sub>. However, because of the overlapping of the broad 257 nm band of Cl<sub>2</sub> with the 261 nm band of AlCl, this correlation is not clear. To test this a silicon slice with an aluminum thin film was etched while the plasma spectrum was repetitively scanned

at 726 nm.  
es. Furthermore,  
ing etching  
o account in

locked parallel  
r. Spectra were  
reso-  
3.56 MHz exci-

Cl<sub>2</sub> at 257,  
is observed  
inum etch  
to the CCl<sub>4</sub> in  
ed while emis-

luminum chamber  
No Cl<sub>2</sub> emis-  
th CCl<sub>4</sub>. BCl<sub>3</sub>  
and of AlCl<sub>3</sub> at  
uminum lines  
. The addition  
ssion due to Al  
ng Cl<sub>2</sub> emission.

ith a rapid etch  
oborate this,  
dized aluminum  
e. The absence  
d suggests that  
Cl<sub>4</sub>. This is in  
s a faster etch-  
mination could  
load locks on  
tiation with  
lasma suppresses  
fficient in the  
oping of the  
this correla-  
an aluminum thin  
vely scanned

between 255 and 265 nm to monitor both Cl<sub>2</sub> and AlCl<sub>3</sub> emission. This is shown in Figure 1. Simultaneously the emission at 395 ± 3 nm was monitored to follow the Al atomic emission lines. This is shown in Figure 2. The atomic emission shows a steep onset and drop off as the slice clears. The 255-265 nm region shows an interesting quenching effect. During the induction period before the penetration of the native oxide film, Cl<sub>2</sub> emission is very strong and no AlCl<sub>3</sub> signal is observed. The appearance of the AlCl<sub>3</sub> signal is accompanied by the decrease and disappearance of the Cl<sub>2</sub> signal. As the slice clears, the process is reversed. This behavior suggests caution in using the 261 nm band of AlCl<sub>3</sub> as an end point for Al etch. The fall of one signal and rise of another overlapping signal could obscure the end point trace.

From the spectral data, BCl<sub>3</sub>/Ar is an excellent etch gas for aluminum oxide. However, when aluminum coated slices are etched with BCl<sub>3</sub>, the etch is very slow unless Cl<sub>2</sub> is added. However, the disappearance of the Al emission from the empty chamber suggests that the addition of Cl<sub>2</sub> to a BCl<sub>3</sub>/Ar plasma reduces the effectiveness of BCl<sub>3</sub> in etching oxide. In both the BCl<sub>3</sub> and CCl<sub>4</sub> plasmas, the addition of Cl<sub>2</sub> suppresses dissociation of the other molecule, causing fewer of the active radicals (either BCl or CCl) to be produced. Adding Cl<sub>2</sub> to BCl<sub>3</sub> apparently nullifies one of the advantages ascribed to BCl<sub>3</sub> plasmas, namely its excellent etch initiation (oxide penetration) characteristics. However, the addition of Cl<sub>2</sub> is necessary to enhance the etch rate of an aluminum film.

The etching characteristics of CCl<sub>4</sub> do not appear to be changed quite so drastically by the addition of Cl<sub>2</sub>. CCl<sub>4</sub>/Ar alone apparently produces considerable amounts of free chlorine as well as sufficient CCl radicals to penetrate the oxide and initiate etch. Addition of Cl<sub>2</sub> increases the atomic Cl concentration and accelerates the etch. A CCl<sub>4</sub> plasma does not etch the anodized aluminum chamber at a spectroscopically detectable rate.

A particularly interesting feature of the spectra of aluminum etch plasmas is the behavior of the Cl<sub>2</sub> band emission at 257 nm. The Cl<sub>2</sub> emission is highly sensitive to the onset and completion of the etch. This behavior is contrasted to that of the atomic Cl emission line at 726 nm. When the Cl emission was monitored during etching under the same conditions as Figure 1, the Cl signal dropped by about 25% after etch initiation, and rose to its original level as the film cleared. Simple depletion of chlorine species does not account for the loss of the Cl<sub>2</sub> signal.

The 257 nm band of Cl<sub>2</sub> is a known bond-to-bond transition originating above the dissociation energy of the chlorine molecule (5). The upper state is ionic in character and the lower state is covalent. The upper state is efficiently pumped by the discharge. The AlCl<sub>3</sub> band originating at 261 nm provides a non-radiative path for

quenching the excited  $\text{Cl}_2$ . Another similar band of  $\text{Cl}_2$  occurs at 308 nm. It is readily observed in the absence of aluminum species in the plasma. Like the 257 nm band, it is quenched by the presence of Al species. In this case, the quenching species is probably the Al atom resonance state originating at 308 nm.

The 261 nm band of  $\text{AlCl}$  is widely reported as a suitable endpoint signal for aluminum etching. However, the behavior of the overlapping 257 nm  $\text{Cl}_2$  band suggests caution in its use. The opposing behavior of the two signals can make the endpoint ambiguous. A preferable signal for  $\text{CCl}_4$  or  $\text{BCl}_3$  plasmas are the Al lines at 394 and 396 nm. No other lines in the region between 390 and 400 nm are detected with either He or Ar diluents. This allows for use of an interference filter to isolate the two lines. As shown in Figure 2, they produce a sharp endpoint under conditions where 261 nm can be ambiguous.

#### References

1. W.R. Harshbarger, T.A. Miller, P. Norton, and R.A. Porter, Appl. Spectroscopy 31, 201 (1977).
2. B.J. Curtis and H.J. Brunner, J. Electrochem. Soc., 125, 829 (1978).
3. R.W.B. Pearse and A.G. Gaydon, The Identification of Molecular Spectra London: Chapman and Hall, 4th edition, 1976.
4. K. Tokunaga, F.C. Redeker, D.A. Danner, and D.W. Hess, J. Electrochem. Soc., 128, 851 (1982).
5. M. McCusken, "The Rare Gas Excimers," in Excimer Lasers, ed. Ch. K. Rhodes. Berlin: Springer-Verlag, 1979.

$\text{Cl}_2$  occurs at aluminum species in the presence of probably the Al

suitable end-behavior of the use. The ppos-nt ambiguous. A lines at 394 and 400 nm are for use of an own in Figure 2, 261 nm can be

A. Porter, Appl.

ic., 125, 829

in of Molecular 1976.

Hess, J.

: Lasers, ed. Ch.




Figure 1.

Repetitive scan during etching an aluminum coated wafer with  $\text{BCl}_3/\text{Ar}$ . The spectrum was repetitively forward and reverse scanned between 255 and 265 nm. The broad band is  $\text{Cl}_2$  emission centered at 257 nm and the sharp spike is due to  $\text{AlCl}$  at 261 nm. During the induction period (A to B) only  $\text{Cl}_2$  is observed. During etching (B to C) only  $\text{AlCl}$  is observed. After the slice clears (C, only  $\text{Cl}_2$  emission is observed. RF is turned off at point D.




Figure 2.

Trace of the signal generated at 395 nm and recorded simultaneously with the trace shown in Figure 1. Signal was detected through a 5 nm half bandwidth interference filter to detect both aluminum lines at 394 & 396 nm. Time scale is compressed by a factor of 3.5 compared to Figure 1. Points A, B, C, D correspond to RF on, etch initiation, etch termination, and RF off, respectively.

**THIS PAGE BLANK (USPTO)**